

Fitting Instructions - FR8DYRWTC
To be used in conjunction with the instructions supplied
with the product



Fix the bulkhead bar using the 4 bolts, fitted into the 4 threaded holes



Bulkhead fitted



Remove the rear tie down points



Attach the rear bracket, fit together with the original tie down points. Do not tighten



Attach side brackets, do not tighten. Lift Roller top into place.



Line up the T-bolts with the side brackets, fit and tighten M6 nut

Fitting Instructions - FR8DYRWTC
To be used in conjunction with the instructions supplied
with the product



Pull the Roller top back and ensure clearance with the tailgate. Then tighten all side arms



Fit 4 Drainage pipes

NOTES: