

# Roll Bar Fitting Instructions For Titan Slide VW Amarok MK3 2023 on (FR8DYRWTC - REF: VA3D023W) -

Step 1: Remove the Roll from the Amarok.



Step 2: Foam for the bulkhead - cut to length.



Step 3: Use a screwdriver to pierce the foam as shown.



Step 4: Fit front bulk aluminium piece.





Step 5: Remove pictured blocks from the feet of the Roll bar (leave the rubber foot in place).



Step 6: Place the blocks, and seal around the edges (pictured below)



Step 7: Use the bolts removed to spread the roll bar wider (see image below) and bolt into position.

